

Contents

AR-888(H): Access Controller

- 1 Product (US/EU)
- 2 User Guide
- 3 Terminal Cables
 - CN1
 - CN2 WG-Input
 - CN4 RS-485
 - CN5 Duress
 - CN9
- 4 Tools
 - Flat Head Hex Socket Screw: M3x8
 - Iron bar*2 (Inserted into Product)
 - Bottom Cover
- 5 EVA foam gasket (US/ EU)

AR-888(K/U): Wiegand Reader (K: With Touch Key Panel, U: W/O Touch Key Panel)

- 1 Product (US/EU)
- 2 User Guide
- 3 Terminal Cables
 - CN1
 - CN2 WG-LED
 - CN4 SOR/FW
 - CN5 WG-Output
 - CN9
- 4 Tools
 - Flat Head Hex Socket Screw: M3x8
 - Iron bar*2 (Inserted into Product)
 - Bottom Cover
- 5 EVA foam gasket (US/ EU)

AR-PBI888: Infrared Touch-Less Sensor / Exit Button

- 1 Product (US/EU)
- 2 User Guide
- 3 Terminal Cables
 - CN2
- 4 Tools
 - Flat Head Hex Socket Screw: M3x8
 - Iron bar*2 (Inserted into Product)
 - Bottom Cover
- 5 EVA foam gasket (US/ EU)

Installation

- Take off two Iron bars from the of bottom body A and and mounting plate B. Pull the cables from the square holes of the eva foam gasket and mounting plate.
- Use a screwdriver to screw the eva foam gasket C and mounting plate B onto the wall with Flat Head Cap Philips Tapping Screws (Excluded, the Installer should prepare before installation. **The screws shall not be screwed too tight, or it could lead to the deformation of the mounting plate.**
- Connect the cables to the backside of body A and attach A to B. To fix A on B by inserting two Iron bars from the bottom of A + B.
- Attach the Back Cover D to A. Use the Allen key and screws to assemble the Back Cover onto the body.
- Hands-off and clear any objects around the 888H/K.** Turn on the power and LED will light-up and beep will sound. Wait the Touch IC start for 10 sec. to operate.



