

CAST-PRO Smoke Detector

Part No. **CP416**



Overview

- A programmable optical CAST-PRO fire detector designed to detect real fires quickly and reduce false alarms effectively.
- Certified to EN54-7 & 17.
- Compatible with C-TEC's ZFP touchscreen-controlled CAST protocol addressable fire panel.
- MASC™ (Miniature Advanced Smoke Detection Chamber) and AFFIRM™ algorithms provide incredible tolerance to false alarms whilst enhancing the detection of real fire conditions.
- Drift compensation functionality.
- Onboard short circuit loop isolator.
- Includes two 8mm x 2mm ultra-bright red LED indicating strips.
- Two detection modes (normal & high sensitivity).
- <1mA alarm current.
- 570uA typical quiescent current @ 40V DC.
- Compatible with C-TEC's CA408 CAST base c/w integrated locking mechanism & ID tag.



More Information

Technical Specifications

Approvals/certifications

Compatibility

Type

Sensitivity

CPR Number 0063- CPR-242190022, KIWA certified to EN54-7 & 17.

Compatible with C-TEC's ZFP CAST Addressable Fire Alarm Systems

Optical smoke detection

2 Detection Modes (normal or high sensitivity, default is normal)



Supply wiring	2-wire, polarity sensitive.
Supply/operating voltage	22 to 40V DC.
Quiescent current	570uA @ 40V.
Alarm current (Imax at Vmin)	<1mA.
Alarm current (Iavg at Vmin)	<1mA.
Sound pressure level (LAFmax) at Vmax at 1m	N/A.
VAD category & coverage	N/A.
Indicators	2 LED indicator strips emitting red light when in alarm offering 360° visibility. Optional remote LED.
Connections	Via CA408 base: 1 +Ve IN (analogue switch); 2 +Ve OUT (analogue switch); 3 Remote LED +Ve; 4 0V; 5 0V; 6 Screen; 7 Screen.
Product dimensions (mm)	105mm diameter x 48mm deep (detector only); 105mm diameter x 65mm deep (detector in base).
IP Rating	IP21C
Weight	118g (not in base); 172g (in base).
Operating conditions/temperature	-10°C to +50°C. Max relative humidity: 95% (non-condensing)
Notes	Requires a CA408 CAST base. CA408R relay base also available.



T 01942 322744 E sales@c-tec.co.uk
F 01942 829867 W www.c-tec.com



C-TEC, Challenge Way, Martland Park, Wigan, WN5 0LD United Kingdom