Piccolo

GRADE 3 INTERNAL SOUNDER



This remotely powered sounder features a piezo sounder and two bright LED's for audible and visual indication. The sound output is selectable for either alternating or continuous tone. It is also protected against tampering by means of lid removal and removal from the mounting surface.

This sounder also has a system status indicator.



- Grade 3 Environment Class II.
- Low profile design
- ≈112dB(A) Sound output
- Selectable alternating or continuous tone
- Flashing alarm indication
- Low current consumption
- Tamper protected lid and mounting
- Can be installed in security systems up to and including Grade 3

Product codes Technical data

Code	Description
SO/PICCOLO/WB/G3	Piccolo Sounder White Blue Lens
SO/PICCOLO/WR/G3	Piccolo Sounder White Red Lens





99	
Sounder Type:	Piezo
Sound Output Level:	≈112dB(A) @ 1 Metre
Sound Only Current:	84mA @ 12v DC
Flash Only Current:	17mA @ 12v DC
Sound and Flash:	100mA @ 12v DC
Operating Temp:	-15°C to +40°C
Material:	Polycarbonate
Dimensions:	125mm x 85mm x 37.5mm







info@cqr.co.uk





Nominal Power Supply: | 12v DC







