



Over Door Lights

HTM6032

Medicare's ODLs can be paired with a number of different call points and are all controlled by wireless technology. The light will illuminate orange, green, flashing yellow, flashing red or flashing blue depending on the call type that has been activated by the paired call point(s). A built in sounder is also provided which can be optionally activated to provide a non intrusive local audible alarm.

Enclosure	High impact styrene
Dimensions (H x W x D)	85mm x 36mm x 85mm
Weight	51g
Operational Modes	Pairs with either a single or multiple call points within a zone and operates on a follow-me light format. Built in operational sounder.
Radio Specifications	433.92MHz
Conformity	Conforms to European EN 301 489-3 and ETSI EN 300 220-3 (for ERP@10mW) RED
Power	A 12 volt dc power supply unit is required using a 2 core cable with 0.75mm standard flexible conductors. Circuits should be wired in a ring circuit, allowance should be made for cable length and volt drop.
Fixing and Installation	Each Over Door Light requires a 1 gang dry line back box