



WIB Interposing Box Signaline WD Connection Device



Termination box for Signaline WD and control equipment Resistant to most acids, alakalis and oils





Tel: +44(0)1252 725257 Revision 1.0 (2021) © 2020/21 LGM Products Ltd.

Email: sales@lgmproducts.com

Web: www.lgmproducts.com ISO 9001:2015 certified

Address: LGM Products Ltd, Unit 15 Riverside Industrial Park, Farnham, Surrey, GU9 7UG, United Kingdom.





Model Signaline WIB

IP rating IP66

Dimensions 94 x 94 x 57 mm

(excluding cable glands)

Enclosure Material Polycarbonate

Lid seals Non ageing polyurethane

Colour options RAL 7035 Grey

Chemical resistance Resistant to most acids, alkalis and oils

Operating temp -35°C to 120°C

The Signaline WIB Water Interposing Box provides a convenient means of interfacing the Signaline WDM-KM Control Module with a Signaline Water Control Panel. One Signaline WIB Water Interposing Box is required per zone.

Each WIB is supplied with appropriately sized cable glands, a terminal block and a 680 ohm resistor.

It is also a quick and efficient method to interface the 6 core data cable from the Signaline WDM-KM Control Module with building management systems and addressable systems.



Tel: +44(0)1252 725257 Revision 1.0 (2021) © 2020/21 LGM Products Ltd.

Email: sales@lgmproducts.com Web: www.lgmproducts.com ISO 9001:2015 certified

Address: LGM Products Ltd, Unit 15 Riverside Industrial Park, Farnham, Surrey, GU9 7UG, United Kingdom.