



The invisible motor for swing gates weighing up to 100 kg and with a leaf length of up to 1.8 m.

24 VDC irreversible electromechanical gear motor.

Minimum visual impact

The motor is small enough to be easily installed inside the profiles of the gate leaf or in very slim posts (with a minimum diameter of 55 mm).

Easy to install

The bottom-up installation simplifies fixing of the motor inside the post.

Resistant

IP67 die-cast aluminium structure:

Oltre resists even the harshest weather conditions.

Quick and reliable

Complete opening (90°) of the leaf in about 10 seconds.

Oltre has been tested for use at 60 cycles/hour, making it suitable for all contexts with intensive use.

Safe

Easy-to-use external manual release: the gate can always be opened manually, without having to take it apart.

Dedicated Moonclever MC824L control unit:

- · easy to programme;
- self-learning of opening and closing limit positions;
- automatic fault diagnostics;
- programming of pause time;
- pedestrian pass door;
- deceleration during opening and closing;
- obstacle detection with dual technology;
- operation in event of power failure by means of optional rechargeable battery (PS324);
- provision for connection of resistive sensitive edges.





| CODE | DESCRIPTION | PCS./PALLET |
|-----------|--|-------------|
| OLTRE1824 | 24 Vdc irreversible for installation on post or leaf profile, with release lever | 20 |

TECHNICAL SPECIFICATION


| CODE | OLTRE1824 |
|------------------------------|---------------|
| ELECTRICAL DATA | |
| POWER SUPPLY (VDC) | 24 |
| CURRENT DRAW (A) | 1 |
| POWER (W) | 25 |
| PERFORMANCE DATA | |
| SPEED (RPM) | 1,5 |
| TORQUE (NM) | 150 |
| WORKING CYCLE (CYCLES/HOUR) | 60 |
| DIMENSIONAL AND GENERAL DATA | |
| PROTECTION CLASS (IP) | 67 |
| OPERATING TEMP. (°C MIN/MAX) | -20 ÷ +50 |
| DIMENSIONS (MM) | 305x145x346 h |
| WEIGHT (KG) | 5,5 |

DIMENSIONS





INSTALLATION DIAGRAM



- MOTOR
- 2. TRANSMITTER
- 3. PHOTOCELLS MOUNTED ON POSTS
- 4. PHOTOCELLS
- 5. FLASHING LIGHT
- 6. CONTROL UNIT
- 7. DIGITAL OR KEY-OPERATED SELECTOR SWITCH
- 8. SYP SOLAR PANEL
- 9. PSY24 BATTERY BOX
- 10. O-VIEW MULTIFUNCTION DISPLAY

- ACCESSORIES ALSO AVAILABLE
 - IN WIRELESS VERSION Solemyo Air Net System
- Solemyo SOLAR POWER ACCÉSSORIES

COMPATIBILITY TABLE WITH CONTROL SYSTEMS AND ACCESSORIES

| | CONTROL UNIT / RECEIVER | | | | | | | | | TF | ANS | MITT | ER | PHOTOCELLS | | | | | | | | | FLASHING LIGHT | | | | | |
|-----------|-------------------------|-----------------|----------------|------------------|-----------------|-----------------|-----------------|--------------|--------------|---------------|----------|---------|----------|------------|-----|-----|-----|------|------|------|------|-------|----------------|--------|---|------|-----|-----|
| CODE | A01 / built-in* | A02 / built-in* | A6F / FLOXI2R* | A700F / FLOX12R* | A60 / 0XI-SMXI* | A500 / FL0XI2R* | A924 / FLOXI2R* | MC424L / 0XI | MC824L / 0XI | MC824HR / 0XI | ERA INTI | ERA ONE | ERA FLOR | NICEWAY | EPS | EPM | EPL | EPSB | EPMB | EPLB | F210 | FT210 | F210B | FT210B | П | EL24 | ELB | WLT |
| OLTRE1824 | | | | | | | | | • | | • | • | • | • | | | | • | • | • | | | • | | | | • | • |

^{*}Radio receiver not compatible with the Opera system

ACCESSORIES



PS324 24 V BATTERY WITH BUILT-IN CHARGER

PCS./PACK. 1



PLA10 VERTICAL 12 V ELECTRIC LOCK (OBLIGATORY FOR LEAFS LONGER THAN 3 M)

PCS./PACK. 1




PLA11 HORIZONTAL 12 V ELECTRIC LOCK (OBLIGATORY FOR LEAFS LONGER THAN 3 M)

PCS./PACK. 1

TS SIGN. PCS./PACK. 1



SOLEMYO KIT FOR SOLAR POWERING OF GATES, GARAGE DOORS AND BARRIERS.



NICE, EASY SOLUTIONS FOR HOME AND BUILDING.

AUTOMATION AND CONTROL SYSTEMS FOR GATES, GARAGE DOORS, AWNINGS, ROLLING SHUTTERS AND ALARM SYSTEMS, WITH INTEGRATED MANAGEMENT THROUGH SMART INTUITIVE INTERFACES: PRACTICAL, FUNCTIONAL AND ELEGANT SOLUTIONS FOR THE IDEAL WAY TO LIVE EVERY SPACE.



